

AMKmotion First steps Initial startup Drive system AMKASYN KE/KW Controller card KW-R06 / -R16 / -R07 / -R17 KW-R24(-R) / -R25 / -R26 Controller AMKAMAC A-series

Version: 2023/26 Part no.: 204539 Translation of the "Original Dokumentation"



MEMBER OF THE ARBURG FAMILY

AMKmotion

Imprint				
Name:	PDK_204539_IB_KE	<w_a5< th=""><th></th></w_a5<>		
Version:	Version: 2023/26			
	Changes		Letter symbol	
	AMKmotion Design		LeS	
Previous version:	2018/04			
Product version:	Product	Firmware version (Part no.)	Hardware version (Part no.)	
	AMKASYN KE/KW with KE-E10 built-in: KE xx -0EU KES xx - 0EU Controller cards: KW-R06 / -R16 / - R07 / -R17 / -R24(- R) / -R25 / -R26	-		
Copyright notice:	© AMKmotion GmbH - Any transfer or reprodu requires express cons the event of the grant of	+ Co KG uction of this document, as well as utilisation or commur ent. Offenders are liable for the payment of damages. A of a patent or the registration of a utility model or design.	nication of its contents, Il rights are reserved in	
Reservation:	We reserve the right to product.	o modify the content of the documentation as well as the	delivery options for the	
Publisher:	AMKmotion GmbH + C Gaußstraße 37-39 73230 Kirchheim unter Germany Phone +49 7021 50 05 Fax +49 7021 50 05-1 E-mail: info@amk-mot Registration court: AG Tax Id no.: DE 145 912 Complementary: AMK	Co KG r Teck 5-0 76 tion.com i Stuttgart, HRA 230681, Kirchheim unter Teck, 2 804 imotion Verwaltungsgesellschaft mbH, HRB 774646		
Service:	Phone +49 7021 50 05	5-190, Fax -193		
	For fast and reliable tro following: • Type plate data • Software version • Device configured • Type of fault/pured • Diagnostic meter • F-mail service@amket	oubleshooting, you can help us by informing our Custom a for each unit on uration and application roblem and suspected cause ssages (error messages)	ner Service about the	
Internet address:	www.amk-motion.com	1		

Content

Imprint	2
1 About this document	2
1.1 Structure of this document	J
1.2 Keening this document	5
1.3 Target group	5
	5
1.5 Display conventions	5
1.6 Appendant documents	5
2 For Your safety	7
2.1 Basic pates for your safety	7
2.2 Sefety rules for handling electrical systems	7
2.2 Salety fulles for handling electrical systems	7
2.3 Flesenting salety messages	7
2.4 Class of flazaid	0
2.5 Used salety alert symbols	0
	0
2.7 Warranty	9
2.8 Always to observe!	9
3 Overview machine startup	12
4 Overview startup motor and converter	13
5 Preparation for startup	14
5.1 Assembly and installation	14
5.2 Electrical connections (Overview)	15
5.3 Installing AMK software products	17
5.3.1 AIPEX PRO	17
5.3.2 AFL AMK function library	17
5.4 Communication connection	17
5.4.1 Direct connection via USB	18
5.4.1.1 Compact power supply	18
5.4.1.2 Compact Inverter	19
5.4.1.3 USB communication settings	19
5.4.2 Direct connection via EtherCAI	20
5.4.2.1 Compact power supply	20
5.4.2.2 Compact inverter	21
5.4.2.3 EtherCAT communication settings	21
5.4.3 Testing the communication	23
6 Electrical startup	25
6.1 System run-up KE/KW	25
6.2 Initial startup motor	28
6.2.1 Creating an online project for initial motor startup	28
6.2.2 Entering motor parameters	30
6.2.2.1 Motors with encoder data base	30
6.2.2.2 Motors without encoder data base	32
6.2.2.3 Third-party motors	33
6.2.3 Configuring limitations and monitorings	35
6.2.4 Activating the motor controller	37
6.2.4.1 Status and control signals	37
6.2.4.1.1 Status signals	38
6.2.4.1.2 Control signals	38
6.2.4.2 Switch-on and -off flow chart	40
6.3 Setpoint setting by startup function	42
6.4 Setting the control loop	45

6.4.1 Tuning the current controller	46
6.4.2 Tuning the speed controller	47
6.4.2.1 Theoretical basis	48
6.4.2.2 AIPEX PRO settings	51
6.4.2.3 Optimising the speed controller	56
6.4.3 Tuning the position controller	58
6.4.3.1 Theoretical basis	59
6.4.3.2 AIPEX PRO settings	59
6.4.3.3 Optimising the position controller	60
7 Initial startup fieldbus	61
7.1 Overview fieldbus wiring	62
7.2 Direct connection via Ethernet	63
7.3 System run-up fieldbus	63
7.4 Logon fieldbus	64
8 PLC programming	66
9 Error diagnosis with AIPEX PRO	67
Glossary	70
Your opinion is important!	72

1 About this document

1.1 Structure of this document

Content	Title	Chapter no.
Validity, usage and purpose of this documentation	Imprint	-
	About this document	<u>1</u>
Safety	For Your safety	2
Overview of steps to carry out	Overview machine startup	3
	Overview startup motor and converter	4
Practical information for carrying out	Preparation for startup	5
(step by step instructions)	Electrical startup	<u>6</u>
	Initial startup fieldbus	7_
	PLC programming	8
Reading diagnostic messages	Error diagnosis with AIPEX PRO	9
Abbreviations and definitions	Glossary	-

1.2 Keeping this document

This document must permanently be available and readable at the place where the product is in use. If the product is used at another place or changed the owner, the document must be passed on.

1.3 Target group

Any person that is qualified and intends to work with this product must read, understand and follow this document:

- Unpacking and installation
- Connection
- Parameterization
- Startup

1.4 Purpose

The document at hand describes the initial startup of an AMK drive system containing the following components:

- compact power supply KE (EhterCAT field bus)
- compact inverter with controller card (KW-R06 used in the examples)
- PLC controller A-series (A5 switch cabinet device without display used in the examples)



KW-R07 / -R17 and iC / iX / iDT5 (with functional safety)

The startup of the functional safety is not part of this document.

Any information about functional safety (e.g. properties, parametrization, diagnostic messages) can be found in the Software description Safety manual; functional safety (Part no. 203446).

This document is addressed to any person who handles the product. It gives information about the following topics:

- Safety messages which are absolutely necessary to take care of during handling the product
- Assembly
- Electrical connections
- Startup and operation

1.5 Display conventions

Display	Meaning
	This symbol points to parts of the text to which particular attention should be paid.

Display	Meaning
'Text'	Parameter names, e.g. ID2 'SERCOS cycle time'
	Diagnostic message, e.g. 1042 'Mains phase fault'
	Name, e.g. Call up the function 'Delete PLC programme'
0x	0x followed by a hexadecimal number, e.g. 0x500A
_ b _	The red hand symbol indicates the button or menu item to click on.
	The red hand symbol indicates the option to be selected.
ни кака кака кака кака кака кака кака ка	Click the right mouse button

1.6 Appendant documents

Device descriptions

Part no.	Title
28932	Servo drives KE/KW
202744	Controller cards KW-R06 / -R16 / -R07 / -R17
204918	Controller cards KW-R24(-R) / -R25 / -R26 / -R27
202975	Controllers A4 / A5 / A6

Functional descriptions

Part no.	Title
25786	Diagnostic messages
204979	Software description AIPEX PRO V3
	(PC software for startup and parameterization)
	(AFL - AMK function libraries)
203704	Parameter description KW-R06 / -R16 / -R07 / -R17, KW-R24(-R) / -R25 / -R26 / -R27, KE (CAN / Ethernet), A4 / A5 / A6
204019	Basic knowledge AMK PLC programming in structured text

2 For Your safety

2.1 Basic notes for your safety

- At electrical drive systems, hazards are present in principle that can result in death or fatal injuries:
 - Electrical hazard (e. g. electric shock due to touch on electrical connections)
 - Mechanical hazard (e.g. crush, retract due to the rotation of the motor shaft)
 - Thermal hazard (e.g. burns due to touch on hot surfaces)
- These hazards are present while starting up and operating the unit, and also during servicing or maintenance work.
- Safety instructions in the documentation and on the product warn about the hazards.
- Personnel must have read and understood the safety instructions before installing and operating the product. In the documentation about the product the usage warnings pertain to direct hazards and must therefore be followed directly when operating or handling the product by the operator.
- AMKmotion products must be kept in their original order, that means it is not allowed to do a significant constructional change on hardware side and software is not allowed to be decompiled and change the source code.
- Damaged or faulty products are not allowed to be integrated or put into operation.
- Do not start the system in which the AMKmotion products are installed (begin of intended use) until you can determine that all relevant standards, laws, and directives have been complied with, e. g. low voltage directive, EMC directive, and the machinery directive, and possible further product standards. The plant manufacturer is responsible for the compliance with the laws, directives, and standards.
- The devices must be installed, electrically connected and operated as shown in the device description documentation. The technical data and the required environmental conditions must be observed at all times.

2.2 Safety rules for handling electrical systems

In particular on drive systems, the instructions pertaining to safety and the following five safety rules have to be kept in the specified sequence:

- 1. Switch off electrical circuits (also electronic and auxiliary circuits).
- 2. Secure against being switched on again.
- 3. Determine that there is no voltage.
- 4. Ground and short circuit.
- 5. Cover or close off neighboring parts that are under voltage.

Reverse the measures taken in reverse order after completing the work.

2.3 Presenting safety messages

Any safety information is configured as follows:

▲ SIGNAL WORD	
	Type and source of risk
\wedge	Consequence(s) of non-observance
Symbol	Steps to prevent:
	•

2.4 Class of hazard

Safety and warning messages are graduated into classes of hazard (according to ANSI Z535). The class of hazard defines the potential risk of harm and is described by a single word, if the safety information is ignored. The signal word is followed by a safety alert symbol (ISO 3864, DIN EN ISO 7010). In accordance with ANSI Z535, the following signal words are used to define the class of hazard.

Safety alert symbol and signal word	Class of hazard and its meaning
A DANGER	DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury
	WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury
	CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury
NOTICE	NOTICE is used to address preventions to avoid material damage, but not related to personal injury.

2.5 Used safety alert symbols

Safety symbol	Meaning
	Generic warning!
	Warning against dangerous electrical voltage!
	Warning against hot surface!

2.6 Requirements for the personnel and their qualification

Only authorized and qualified personnel may work on and with the AMK motion drive systems.

Specialised personnel must:

- Perform mechanical and electrical work that is described in this documentation, such as mounting and connecting
- Observe all information in the documentation accompanying the product in order to work with the product safely and in an error-free manner
- Understand and know hazards that occur when handling the product
- Know connections and functions of the system
- Be familiar with the control concept in order to operate the drive system
- Be authorized to switch circuits and devices on and off, ground and label them
- Observe local specific safety requirements

2.7 Warranty

- All information in the documents accompanying the product must be complied with for a safe and trouble-free operation.
- The assertion of warranty claims is excluded if the information in the documents is not observed completely.
- Hardware and firmware may not be modified except by personnel authorized by AMKmotion and after consultation with AMKmotion.
- The company AMKmotion GmbH + Co KG is not liable for damages from unintended use, incorrect installation or operation, exceeding rated values and non-observance with the environmental conditions.

2.8 Always to observe!

۹	Danger to life!
	The controller cards KW-R07 / KW-R17 / KW-R27 are safety modules according to the Machinery directive MRL 2006/42/EG. Before the cards are put into operation, the executing person must have read and understood the device description and the safety manual. During the startup, all information in these documentation must be taken into account.

	Danger to life from touching electrical connections!	
	Electrical terminals and connectors carry voltages that may cause death or serious injury upon contact.	
	Steps to prevent:	
	Prior to any work on the device: Observe the 5 safety rules.	
$\overline{7}$	Measure the terminal voltages. There may be no voltage present.	
	 Plug and pull connections only when there is no voltage. 	
	 For devices that are connected to a DC bus, or generate it yourself, you need to consider the discharge times of the dc bus capacitors mentioned in the converter documentation 	
	• Before commencing work, the connections must be isolated from the voltage supply at both ends! (both ends mean: AC and DC bus supply side)	

	Danger to life due to unexpected movements!	
	The drive will be torque-free in the status 'Safe torque off (STO)', in case of mains failure or in case of faulty drive controller. External application of force on the drive axis may result in life-threatening movements (e.g. hanging axes can fall down).	
	Steps to prevent:	
	 Install an external, mechanical brake that prevents a movement. 	
	Install a counterweight in order to maintain the axis in balance.	

	Motor shaft movement (rotating parts)!	
	Hair, body parts and clothes can be captured and wrapped by rotating parts and people result suffer fatal injuries.	
	Hazardous motor movement occurs when the motor shaft moves in an uncontrolled or unintentional manner.	
	Even the intended drive movement may be hazardous, if persons remain inside the machine's range of movement.	
	Uncontrolled motor shaft movement occurs when the motor is no longer controllable. Depending on the type of machine, this may have lethal consequences. Possible causes include the following:	
	Faulty wiring, e.g., faulty phase sequence while connecting motor	
	Faulty components	
	Faulty motor parameters	
A	Software error	
	Unintended motor shaft movement is caused by errors in the motor control. Depending on the type of machine, this may have lethal consequences. Possible causes include the following:	
	Operator errors	
	Controller or application program faults	
	Faulty setpoint specification and scaling	
	 Improper operating mode The monitoring devices in the drive system are capable of detecting various fault states. Their purpose is to reduce the drive speed to zero in a controlled manner before switching off the power supply. However, the monitoring devices by themselves are not sufficient to completely and reliably prevent uncontrolled movement. Uncontrolled movement cannot be prevented completely, even if it occurs only for a brief period of time before a monitoring device trips and shuts down the drive or switch off power supply. Steps to prevent: 	
	Always ensure that the is fully de-energized before commencing work on the	
	 Check the limit values for torque, speed, and position, as well as the acceleration and deceleration ramps. 	
	Specify the maximum permissible process speed and set ID113 accordingly.	

Danger to life from touching electrical connections!

The permanent magnets of the rotor induce dangerous voltage at the motor connections when the axis rotates, even when the motor is not electrically connected. If the motor is connected to an inverter, the induced DC voltage is linked to the .

Steps to prevent:

- Make sure that the motor shaft does not rotate.
- Make sure that shock-hazard protection is installed at the motor connections.
- Make sure that the terminals are free of voltage.

The optional motor brake is a holding brake and does NOT provide sufficient protection for persons.

Hanging axes can fall and lead to severe injury.

Risk of injury from hanging axes

Steps to prevent:

- All hanging axes must be mechanically secured against falling with a fall arrester or a supplementary external brake, for instance.
- People must not stand under hanging loads

	Risk of burns when touching hot surfaces!			
	The casing temperature, for example of the line filter, the choke or the brake resistor, can be more than 70 °C during and even after operation. Contact causes burns.			
	Steps to prevent:			
	Make sure that the surfaces have cooled down before you touch.			
	Wear protective clothing such as gloves if hot parts need to be touched.			
	Fit a warning sign with warning hot surface.			
	Do not mount any flammable objects near the device.			

3 Overview machine startup

The startup of a machine, depending on the drive system, is separated into different steps. The following flow chart shows the sequence of the steps.



(*1) The PLC programming is part of the 'Software description AFL - AMK function libraries', Part no. 205795.



KW-R07 / -R17:

For the machine startup of a controller card with functional safety, the safety functions must be de-activated. Therefore, the safe inputs must be connected stringently, and the SafePMT parameter set must be adapted. Without these adaptations, the startup of a servo motor is not possible.

See document 'Safety manual; functional safety' (Part no. 203446), chapter 'Running KW-R07 / -R17 without functional safety'.

4 Overview startup motor and converter

The startup of an AMK drive system is separated into different steps. The following flowchart shows the step-by-step process.



5 Preparation for startup



*1 for PLC programming acc. to. IEC 61131

5.1 Assembly and installation

Mounting KE/KW modules onto a liquid-cooled coldplate See document 'Liquid-cooled cold plate KW-CP', Part no. 200043.

Mounting KE/KW modules onto an air-cooled coldplate See document 'Fan-cooled cold plate KW-LK', Part no. 202393.

Mounting KE/KW modules with integrated air-cooling system See document 'Servo drives KE/KW', Part no. 28932 chapter 'Installation of modules with integrated air cooling'.

5.2 Electrical connections (Overview)

For the initial startup of a drive, you need the following connections: (Example KE 20 and KW 2 with KW-R06)



Connections compact power supply

Connection	Use
H1 - H5	LED status display
S1	Dip switch (device addressing)
X01	Mains connection (external main connector)
X02	DC bus
X03(.1)	External braking resistor
X03.2	External braking resistor
X06	DC bus
X08	Input 24 VDC external power supply
X09	Transmission 24 VDC (total of max. five modules per group)
X20	Power supply to charging circuit, control for main contactor
X21	2 binary outputs
X22	2 binary inputs, 2 binary outputs
X25	PTC thermistor for monitoring temperature of external components such as brake resistors and mains filters
X85	Real-time Ethernet IN
X86	Real-time Ethernet OUT
X235	Mini USB interface for firmware update and parametrisation

For detailed information about system configuration, switch-on components, charging circuit, and mains connection as well as terminal assignments, wire diameters, cable confection and tightening torques: See document 'Device description Servo drives KE/KW' (Part no. 28932)

Connections compact inverter

Connection	Use
X04	Motor connection
X05	DC bus transmission (max. connected load 60 kVA)
X06	DC bus (max. connected load 100 kVA)
X08	Input 24 VDC external power supply
X09	Transmission 24 VDC (total of max. five modules per group)
X12	PTC thermistor for monitoring motor temperature
X13	Acknowledgement power output stage enable (transmission)
X14	Power output stage enable (transmission)
X15	Power output stage enable EF / EF2
X16	Acknowledgement of power output stage enable
X17	Power output stage enable EF EF2
X18	Power output stage enable transmission



The two axes of a compact double inverter KWD are distinguished by labelling A and B. e.g. X04A and X04B are the different motor connections

For detailed information about system configuration and switch-on components as well as terminal assignments, wire diameters, cable confection and tightening torques: See document 'Servo drives KE/KW' (Part no. 28932)

For more information about EF connection:

See document 'Device description Servo drives KE/KW' (Part no. 28932), chapter 'Function description KW'.

Connection ¹⁾	Use
XS20	Functional Safety: Safety I/O (only KW-R07 / -R17)
X85 / X86	Real-time Ethernet IN/OUT
X130	Resolver
X131	Sinus encoder input
X132	Square-wave pulse interface
X137	ACC bus
X140	Binary inputs and outputs
X141	Binary i/O and analogue inputs
X235	USB

Connections controller card

1) The availability of the interfaces depends on the type and the functionality of the used controller card

For detailed information about connection of the controller card, terminal assignments, wire diameters, cable confection and tightening torques:

See document 'Device description Controller cards KW-R06 / -R16 / -R07 / -R17' (Part no. 202744) and Controller cards KW-R24(-R) / -R25 / -R26 / -R27, chapter 'Electrical Connections'.

5.3 Installing AMK software products

5.3.1 AIPEX PRO

Install the AMK software AIPEX PRO (Part no. 0811).

AIPEX PRO contains parametrisation and startup software, a IEC 61131-3 programming editor and a firmware flasher.

Required AIPEX PRO version:

KW-R06 / -R16 / -R07 / -R17≥ AIPEX PRO 1.09 SP2

KW-R24 / -R25 / -R26≥ AIPEX PRO 3.0

KW-R24-R / -R27 ≥ AIPEX PRO 3.03

The software must be installed to a PC with operating system Windows® 2000 / XP / Vista or 7. You need local administration rights for installation

For detailed information about AIPEX PRO:

See document 'Software description AIPEX PRO V3' (Part no. 204979).

5.3.2 AFL AMK function library

For PLC programming, you need the AFL AMK function library (Part no. 0877) in addition. The AFL library contains standard function blocks to access easily to all standard functions of the controllers, power supplies, and drives.

For detailed information:

See document #Software description AFL - AMK function libraries' (Part no. 205795).

5.4 Communication connection

For initial startup, establish a direct connection between your PC with AIPEX PRO and the AMK device.



A direct connection is a point to point connection between PC and AMK controller.

Siehe 'Direct connection via USB' auf Seite 18. Siehe 'Direct connection via EtherCAT' auf Seite 20.

5.4.1 Direct connection via USB

5.4.1.1 Compact power supply

For reading the device data with AIPEX PRO, you will need a 24 VDC power supply at the compact power supply. Connect the PC with installed AIPEX PRO to the USB interface X235 of the compact power supply. Use an AMK USB cable with ferrite core (Part no. 47058).



5.4.1.2 Compact inverter

For reading the device data with AIPEX PRO, you will need a 24 VDC power supply at the compact inverter.

Connect the PC with installed AIPEX PRO to the USB interface X235 of the inverter. Use an AMK USB cable with ferrite core (Part no. 47058).



24 VDC power supply

5.4.1.3 USB communication settings

If you use the USB connection, no communication settings must be done.

5.4.2 Direct connection via EtherCAT

5.4.2.1 Compact power supply

For reading the device data with AIPEX PRO, you will need a 24 VDC supply voltage at the compact power supply. Connect the PC with installed AIPEX PRO to the Ethernet IN interface X85 of the compact power supply. Use an Ethernet standard RJ45 twisted pair patch cable.



5.4.2.2 Compact inverter

For reading the device data with AIPEX PRO, you will need a 24 VDC supply voltage at the compact inverter. Connect the PC with installed AIPEX PRO to the Ethernet IN interface X85 of the compact inverter. Use an Ethernet standard RJ45 twisted pair patch cable.



24 VDC power supply

5.4.2.3 EtherCAT communication settings

EtherCAT master

On a point to point connection via EtherCAT, the PC works as EtherCAT master. The Ethernet network settings of the PC are not to be changed.

EtherCAT slave

The connected drive (compact power supply or compact inverter) establishes the EtherCAT slave. Its network settings must be adapted:

Start AIPEX PRO

Start menu 'Extras' \rightarrow 'Options'



In register 'PC Communication', the EtherCAT communication can be activated and de-activated. You can shorten the initialising phase by selecting the used Ethernet adapter of your interface.

Options	×
Base Settings PC Communication Configuration create Data Update	
Ethernet, COM-Ports Monitor	
TCP Communication	
CANClient	
C active	
1 MBit	
EtherCAT	
C active	
Adapter Scan all	
OK Abbrechen Ü <u>b</u> ernehmer	
	- 1

Prerequisite WinPcap:

WinPcap will be automatically installed with AIPEX PRO



When installing WinPcap, the option 'Automatically start the WinPcap driver at boot time' must be activated mandatorily.

This option cannot be set later, a new installation will be necessary.



Modified communication setting require AIPEX PRO to be restarted.

5.4.3 Testing the communication

- Connect the 24 VDC power supply to the device. Siehe 'Direct connection via USB' auf Seite 18. Siehe 'Direct connection via EtherCAT' auf Seite 20.
- 2. Start AIPEX PRO
- 3. After the initialisation is terminated, the green PC symbol in the status bar shows the activated connection between the AIPEX PRO PC and the AMK device.

Prerequisites:

- communication is defined in AIPEX PRO
- connecting cable between PC and device
- AIPEX PRO window maximised (full screen)

AMKmotion

🖏 Unbenannt - AIPEX PRO	
Project Online Edit View Extras Startup	Configuration ?
🍋 🗢 🖨 😫 🚆 🗰 🚔 🔶 🥌	🛙 X 🍋 📾 😂 🔪 🍮
PC	Properties Picture
Offline Config Paran Ress + Scop	Components Display all elements Accept

green symbol no resp. red symbol activated connection between the AIPEX PRO PC and the AMK device

- no connection established
- no interface defined
- AIPEX PRO window not at full screen

multiple communication interfaces activated in AIPEX PRO

two-coloured symbol (green / red)

6 Electrical startup



6.1 System run-up KE/KW

The SBM 'System ready message' acknowledges the error-free run-up of the devices and is prerequisite for activating the motor control.

If an error occurs during the system run-up, it is signalised by the LEDs of the compact power supply or the controller card of the compact inverter. By means of AIPEX PRO, details can be read. Siehe 'Error diagnosis with AIPEX PRO' auf Seite 67.

System run-up KE without fieldbus system



System run-up without fieldbus system

Example KW-R06



6.2 Initial startup motor



6.2.1 Creating an online project for initial motor startup

On an online project, the properties and parameter values of a physically existing drive system are transferred to the AIPEX PRO software.

Prerequisite: successful communication test. Siehe 'Testing the communication' auf Seite 23.

Transferring parameters online to the AIPEX PRO project

Click to the 'Logon' button to scan the connected drive system

🚟 Unbenannt - AIPEX PRO		
Project Online Edit View Extras Startup	Configuration ?	
🗅 😂 🖬 🕫 関 🎘 🗰 🛸 😤 🚧	🛛 X 🖻 📾 😂 놀 🍮	
ONLINE	Properties - PC Serial connector	Picture

The 'Import online' window starts automatically and show all connected devices. Click to 'Accepted to the project complete' to transfer the data to the project.

🐨 Unbenannt - AIPEX PRO		
Project Opline Edit View Extras Start	Import online 🛛 🛛 🖄	
	⊟D PC	
🗅 😂 💾 🕰 🚼 🕱 🗰 📦 🥇	🖻 🔫 EtherCAT - Connector	
	🖻 🚹 Antrieb 1	
		Picture
	Motor	
	Ė~ KW-R06	
	🛓 🕂 🥵 10	
	II Option 1	
	🖻 cia ACC - Connector X137	
	🗄 🚹 Supply 33	
	⊨	
	🛓 💮 🔨 10	
	_	
	Accepted to the project complete	
🚯 Cor 🗔 Pai 🔗 Mei 🚧 Sci 🕂 Di	You can copy the devices or project data over	

The connected devices are displayed in the device tree.

Click RMB in the device tree window and 'Tree display set...' to select the device types to be shown in the device tree window.

AMKmotion

The transferred project data should be saved to a storage medium (e.g. hard disk). 'Project' \rightarrow 'Save as...'

🐨 Unbenannt - AIPEX PRO			_ _ _ ×
Project Online Edit View Extras Startup Config	juration ?		
New Ctrl+N Open Ctrl+O Save Ctrl+S	🐰 🖻 📾 🎒 Properties -	Antrieb 1	Picture
Save as Close Import Export data set	Device Softwareversion Type Ser. no.	KW Compact i ▲ KW 108 1128 KW 2 1131385	
Export all data sets Import data set	Part number Station name	0000046304 Antrieb 1	
Admin History Info	Data set name EtherCAT Connector	RefFahrt X85-X86	
Print Ctrl+P Print Preview Page Setup	Bus name Bus physics Address	EtherCAT ETHERCAT 1	

6.2.2 Entering motor parameters

	Danger from uncontrolled rotational movements of the motor shaft!		
	If the motor parameters are entered faultily, the motor cannot be controlled and it might move unexpectedly as soon as the controller enable signal (RF) is activated.		
	Steps to prevent:		
	 Recheck the entered motor parameters before setting the RF signal. 		
	Make sure that no person stays within the vicinity of the machine when setting the RF signal after entering the motor parameters for the first time.		

The process depends on the type of the implemented motor encoder system

AMK absolute encoder type E, F, P, Q, S, T, U, V and Y

Siehe 'Motors with encoder data base' auf Seite 30.

AMK I encoder or resolver

Siehe 'Motors without encoder data base' auf Seite 32.

Third-party motor

Siehe 'Third-party motors' auf Seite 33.

6.2.2.1 Motors with encoder data base

The encoder data base of AMK absolute encoder types E, F, P, Q, S, T, U, V and Y contains all relevant motor parameters needed for the initial startup.

In state of initial loading, the encoder data base is read automatically. As soon as the motor parameters were changed, this function is not active any more.

A motor part number displayed after system run-up shows that the motor parameters of the encoder system were transmitted to the controller. For checking purposes, you can compare the displayed part number with the data on the motor type plate.

🚟 Unbenannt - AIPEX PRO		
Project Online Edit View Extras Startup	Configuration ?	
🗋 🗅 😂 🔚 4 🖳 🎇 🦛 📑 🐳	🛛 X 🖻 📾 🎒 🏊 🍮 🍮	
PC Antrieb 1 KW 2 KW 2 KW 2 KW - no6 Cor Pa Me So Die	Properties - Motor Motor Part number motor A1105AD Optional P-Set 1 Optional P-Set 2 Optional P-Set 3 	Picture

6.2.2.2 Motors without encoder data base

For motors without encoder data base (type I or R encoder), the relevant motor parameters for initial startup can be imported from the motor data base integrated in AIPEX PRO.

Your will get the motor ID (part number) from the motor type plate.



Motors not existing in the database can be added like third-party motors. Siehe 'Third-party motors' auf Seite 33.

6.2.2.3 Third-party motors

You can add any third-party motor to the AMK motor data base. Manually generated data sets will remain after an AIPEX PRO update.



Enter all relevant motor parameters.

Parameter	ID	Value	Unit	
Motor_type	141	Motor_new		
part_number_motor	34160	test 🔒 🖕	1	
Standstill_current	34096	4.53 💾 1	A	
Nom_torque	32771	2.3	Nm	
Nom_velocity	32772	4000	U_min	
Nom_motor_voltage	32768	350.0	٧	
Motor_nom_current	111	2.70	A	
Magnet_current_IM	32769	10.00	A	
Magnet_current_IM1	32770	0.00	A	
Motor_peak_current	109	16.00	A	
Stand_I_max	34168	0.7	s	
Pole_number_motor	32775	10		
Resistance_Rtt	34164	3.00	Ohm	
Inductance_Ltt	34167	5.4	mH	
Rotor_time_constant	32774	0.010	s	
Inductance_LD	34046	3.50	mH	
Inductance_LQ	34045	3.50	mH	-

The third-party motor will be displayed with a yellow symbol.

AMK Motor Database 13,	/11 🔀
🏘 Motor type	🙀 Motor ID
OT10-200-20-FOW	T1111AD
OT4-4-10-ROO	St_DT4-4
Motor_new	test
DT4-2-10-ROO	St_DT4-2
🔵 DT4-1-10-ROO	St_DT4-1
● EBM-230-270-20	51484AD
DP7-30-10-FBO	N363BD
DT5-5-10-FBO	Messe
DVSA24-7-10-4-HBO	MBB759BD
DT5-13-10-POO	M3141
DT3-0,5-10-POO	M3096
OT7-80-20-POW	M3079
DTK5-QOO	M3065
OS10-45-6-SBF	KALMOT40
DT10-200-20-FOW	KALMOT100
OS13-250-6-EOW	KALMOT040
OT7-72-20-FBW	KALMOT020
9	3ort
Accept parameters	Close

By means of 'Export', the selected data set is saved to the hard disk as *.mdb file. This *.mdb file can be imported to another AIPEX PRO project ('Import')



6.2.3 Configuring limitations and monitorings

Hazard due to changing parameters!
The incorrect entering of parameters into the controller card significantly influences the drive system characteristics and creates an increased risk of accidents and damages!
Steps to prevent:
• Change parameters only if you are sure of the meanings and the consequences. If you are unsure, read the parameter documentation or ask the manufacturer or supplier.

Adapting the following parameters reduces the risk of personal injury or material damage during the initial startup. ID113 'Maximum speed'



Adjust ID113 so that the entered speed plus 25 % does not cause any damage within the process.

AMKmotion

ID82 'Positive torque limit'

ID83 'Negative torque limit'



Start with small limit values, e.g. of 5 % and increase in small steps. .

These parameters can be increased during operation by means of the menu 'Startup' \rightarrow 'Temporary parameters'.

If the entered limit is too small, the motor can not start to rotate, because the breakaway torque is greater than the entered limit value.

ID38 'Positive velocity limit'

ID39 'Negative velocity limit'



Start at limits of ± 50 1/min. These parameters can be increased during operation by means of the menu 'Startup' \rightarrow 'Temporary parameters'

ID32782 'Deceleration ramp RF inactive'



Adjust ID32782 so that the entered value does not cause any damage to the mechanical system during braking down.

ID159 'Excess error' ID32922 'Residual distance erase window' ID34182 'Limit position increment'

ID32773 'Service bits' Bit14 = 1 (i²t monitoring of motor inactive)



The modifications of the above mentioned parameters become valid after setting the RF signal (controller enable) or the next system run-up.

Example: parameter modification by entering a new value

👯 Unbenannt - AIPEX PRO					<u>×</u>
Project Online Edit View Extras Startup Configur	ation ?				
🗋 🖆 🖨 💭 🎉 🦛 📑 🖉	6 6 6 6 1 5 5				
	SIII Parameter Selection				
George USB (MSG) - Connector	da ID da Name	Value	(1		M Value
	💾 🕘 Im speed	6000	-	->	6000
Motor 4	114 Overload limit motor	50.0 4 5	<	⇒	50.0 💻
	115 Position feedback type	🔤 0000 0000 0000 0000	<=	⇒	0000 0000 0000 0000
E-main KW-R06	arch	X	<	⇒	20480
Option 1			<	⇒	100
OK OK			<	⇒	10
Search ID-number:				⇒	10
KEN 5			4	⇒	10.0000
Interface		30	4	⇒	50
	125 Velocity Threshold Nx	1000	<	⇒	1000
		pa val		r	
🚺 Confi 🔄 Param 🔗 Mess 👫 Scop 🕂 Diagr	P-Set 0 P-Set 1 P-Set 2	P-Set 3 Inst	0 Inst 1	<u>Inst</u>	2 Inst 3
1					

The value is modified within the AIPEX PRO offline data set on the PC. It must be transferred to the online data set on the device.

Maximaldrehzahl - I	id 113 / Antrieb	1	\times
Transfer cha	anges also to the or	nline data set?	
Yes	Yes always	No	
Example: parameter modification by means of an input window

🚾 Unbenannt - AIPEX PRO					>	<
Project Online Edit View Extras Startup Configu	ration ?					
🗋 🗁 🔚 4 😫 🌋 🦛 🖨 🛶 📗	X & 6 4 2 5 5					
PC	SIII Parameter Selection					
E-Connector	🙀 ID 🏘 Name	Value		ه	M Value 🔺]
	32 4 3 ice bits		-	-	0000 0000 0000 0000 0001	
Motor	32774 Rotor time constant	A 5	<=	⇒ ।	0.010	
	32775 Pole number motor	10	<=	⇒	10	4
E	earch	X	<=	_	512	1
U U U			<=	>	10	
Rest of the second sec		OK 🖡 🖕	<	-> :	3000	
E- 🔐 Supply 33	Search ID-number: 32773	Canad 44	<=	> 1	0.0000	
KEN 5			<	>	100	
Interface	Derox Decen ramp	100	<=	⇒	100	
	32782 Decel.ramp RF inactive	100	<		100	1
		novol		1		
Conti Paran 🕾 Mess 👫 Scop 🕂 Diagr	P-Set 0 P-Set 1 P-Set 2	P-Set 3 Inst 0	Inst I	j inst 2	<u>Inst 3</u>	
9 1					📜 🗌 NUM 🦳 🦯	//.

AM ID32	773 Service bits			
Bit(s)	Description	🙀 Assignment	$\lfloor - \rfloor$	
0	Monitor of the sine encoder and resolver signals	1 - Active	Ĺ	
2	Motor deceleration control at RF withdrawal	1 - Active	Ιг	Cancel 4
5	Operation mode after RF withdrawal	0 - Operation mode like before RF withdrawal is maintained 💌	-	
12	Rectangular pulse encoder input X132 monitor	1 - Active		
13	Monitor acknowledgement motor holding brake	0 - Inaktive		Help
14	I*I*t-motor monitor	0 - Inactive		
16	Assign a negative value to motor direction	0 - With a positive setpoint value, the motor turns clockwise 🗙)1	
18	Reduced DC bus voltage increase	0 - Inactive	ĺ.	
25	Actual speed value polarity inverting active	0 - Inactive		
26	Voltage control with feedforward for synchronous machin	0 - Inactive		
28	Software commutation	0 - Software commutation with alignment to zero position act 💌		

The value is modified within the AIPEX PRO offline data set on the PC. It must be transferred to the online data set on the device.



6.2.4 Activating the motor controller

The motor controller is activated by the 'controller enable' signal (RF).

Prerequisite are the 'system ready message' (SBM; devices are run-up error-free) and the 'acknowledgement DC bus on' (QUE; DC bus is charged).

The parameters ID32795 'Source UE' and ID32796 'Source RF' define the sources of the control signals.

RF can be set by a binary input or a PLC command as well as an AND operation of both.

UE can also be commanded by binary inputs or PLC. Furthermore, it can be transferred automatically from the SBM signal.

Operations (PLC AND binary input) or (SBM AND binary input) are possible.

The default setting is activation by binary input.

6.2.4.1 Status and control signals

The operation state of the drive system will be commanded and acknowledged by means of control and status signal.

The optional EF logic (power output stage enable) has to be controlled by binary inputs and outputs. Any other signals and states can controlled and read by binary inputs and / or fieldbus.

6.2.4.1.1 Status signals

Signal	Name	Meaning
SBM	'System ready message'	After system booting without an error, SBM will be set and shows that the system is free of error.
		In case of an error SBM will be reset and a diagnosis message will be generated. The system reaction in case of an error (e.g. running out, brake down according ID32873 'Deceleration ramp RF inactive', system booting abort) depends on the kind of error. (See document Diagnostic messages (Part no. 25786), chapter Meaning of the diagnostic messages.
		The diagnosis messages can be read out with the software AIPEX PRO or read and evaluated by a controller. After the error cause is removed a system booting (ID33730 'System booting') has to be executed.
QUE	'Acknowledgement DC bus on'	QUE acknowledges that the DC bus voltage is inside the valid range.
QRF	'Acknowledgement controller enable'	QRF acknowledges the active control mode of the drive. Setpoints can be set depending on the configured operation mode (ID32800). If QRF = 0 the drive is free of torque and no control mode is active.

Default adjustments

Signal	Hardware	LED	Terminal	Parameter	Code	Reflection	PLC access
SBM	Compact power supply	H1 'green'	X21 Pin 1 (BA1)	ID32865	33029	-	FB STANDARD_KE
QUE	Compact power supply	H1 'green flashing'	X21 Pin 2 (BA2)	ID32866	33030	-	FB STANDARD_KE
SBM	Controller card KW- R06 / -R16 / -R07 / -R17	H2 'green'	X141 Pin 2B (BA2)	ID32866	33029	ID34120 Bit1	FB STANDARD_ AXIS
	Controller card KW- R24(-R) / -R25 / -R26 *	-	X140 Pin 2B (BEA2)				
QRF	Controller card KW- R06 / -R16 / -R07 / -R17	H2 'green flashing'	X141 Pin 2A (BA1)	ID32865	33031	ID34120 Bit0	FB STANDARD_ AXIS
	Controller card KW- R24(-R) / -R25 / -R26 *		-	-	-	-	-

6.2.4.1.2 Control signals

Signal	Name	Meaning
FL	'Clear error'	FL causes a system booting after the reason for an error message is remedied and the drive is still in error state SBM = 0). The sucessfully finished system booting is acknowledged with the SBM = 1 signal. Clear error can only be executed if $RF = QRF = 0$ by a pulse signal ≥ 1 ms on the binary input or via fieldbus interface.
		Clear error can be executed as follow:
		Configuration FL to an binary input
		ID99 'Diagnosis reset status class 1'
		ID32913 'Clear error'
UE	'DC bus on'	UE activates (signal-edge controlled) the loading procedure of the DC bus capacitors in the power supply device. UE can only be executed if SBM = 1. A successfully finish of the charging procedure is acknowledged by QUE = 1. If UE is reset, the capacitors will be discharged, QUE will be reset.
		Between 2 consecutive UE on signals, a device specific inhibit time has to be considered. See document Servo drives KE/KW (Part no. 28932), chapter Product planning, subtopic Inhibit Time for Control Signal UE.

Signal	Name	Meaning
RF	'Controller enable'	RF (signal-edge controlled) causes a system booting if at least one parameter has been changed before. RF activates the motor control in the current operation mode (e.g ID32800 'AMK main operating mode'. The motor is energized, setpoints are processed and the acknowledgement signal QRF will be set. RF can only be activated if SBM = QUE = 1. If RF is set, the power output stage are active. For devices with the option 'external power output stage enable' additionally EF/FE2 = 1 must be set. If the prerequisites are not fulfilled, the device generates an error message and resets SBM if someone try to set RF. IF RF is withdrawal during operation the motor is ramped down according ID32782 'Deceleration ramp RF inactive' until standstill (≤ 6 RPM) and unenergized. QRF will be reset. If a motor holding brake is active the signals RF and QRF on/off will be delayed device internal, depending on parameter ID206 'Drive on delay time' and ID207 'Drive off delay time'.
optional:		
EF/EF2	'Power output stage enable'	Interrupting the control inputs EF/EF2 will cause the trigger signals for control of the power output stages to be safely blocked in two channels. The motor is in a secure state torque off protected against restart. This safety function is certificated according to EN ISO 13849-1:2008 (Cat.4, PL e) and EN 954-1: 1996, cat. 4. See document Device description Servo drives KE/KW (Part no. 28932), chapter Function description KW, Function description - EF safety function.

Signal	Hardware	Terminal	Parameter	Code	Image	PLC access
UE	Compact power supply	X22 Pin 2 (BE2)	-	-	-	FB STANDARD_KE
FL	Compact power supply	X22 Pin 1 (BE1)	-	-	-	FB STANDARD_KE
RF	Controller card KW-R06 / -R16 / -R07 / -R17	X140 Pin 3B (BE1)	ID32978	32904	ID34100 Bit0	FB STANDARD_ AXIS
	Controller card KW-R24(- R) / -R25 / -R26 *					
FL	Controller card KW-R06 / -R16 / -R07 / -R17	X140 Pin 2B (BE2)	ID32979	33913	ID34100 Bit1	FB STANDARD_ AXIS
	Controller card KW-R24(- R) / -R25 / -R26 *	-	-	-	-	-
optional:						
EF	Compact inverter KW	X15 Pin 2,4	-	-	-	-
EF2	Compact inverter KW	X15 Pin 1	-	-	-	-
EF	Compact inverter KWD/KWZ	X17 Pin 3	-	-	-	-
EF2	Compact inverter KWD/KWZ	X17 Pin 1	-	-	-	-

Control signal motor holding brake

Signal	Hardware	Terminal	Parameter	Code	Reflection
Activating motor holding brake	controller card	X140 Pin 1A	ID32867	33052	ID34120 Bit3
KW-R06 / -R16 / -R07 / -R17					
Activating motor holding brake					
KW-R24(-R)/-R25/-R26*					

For detailed information: See document 'Function descriptions' (Part no. 203878), chapter 'Actuation of the motor holding brake'.

* The controller card has 3 multifunctional BEA (BEA 1-3). Each BEA can use as input or output. Inputs and outputs can be mixed. E. g. BEA1 and BEA2 are inputs, BEA3 is configured as output.







*1	Close emergency OFF circuit (if existent).
*2	The module specific 'System ready' messages (SBM = 1) from the KE and KW modules signal the error-free states. The monitoring of these messages takes place in the higher-ranking controller. Time to SBM > 2 s.
*3	If present, the required external main contactor is actuated by the KE. The delay time until the contactor is actuated via terminal X20 (EH1/EH2) depends on the DC bus capacities connected to the KE.
*4	Only devices with EF logic:
	Hardware signal EF/EF2 must be applied at the latest at that time.
*5	Delay time until QRF is set depends on the connected motor resp. whether the data set must be newly calculated because of a modification of drive specific parameters.
*6	Only devices with EF logic:
	Reset hardware signal EF/EF2 if the motor has to be in a safe torque-free state afterwards.

*7	RF will be disabled via BE. BE is linked with PLC signal, see ID32796 'Source RF'.
*8	Motor is braked to a standstill after the ramp ID32782 'Deceleration ramp RF inactive'.
*9	Pulse ≥ 1 ms.
*10	Each inverter generated a DC bus error.

Explanation of the status and control signals: Siehe 'Status and control signals' auf Seite 37.



KW-R07 / -R17:

For the machine startup of a controller card with functional safety, the safety functions must be de-activated. Therefore, the safe inputs must be connected stringently, and the SafePMT parameter set must be adapted. Without these adaptations, the startup of a servo motor is not possible.

See document 'Safety manual; functional safety' (Part no. 203446), chapter 'Running KW-R07 / -R17 without functional safety'.

6.3 Setpoint setting by startup function

	Motor shaft movement!				
	Hazardous motor movement occurs when the motor shaft moves in an uncontrolled or unintentional manner.				
	Decouple the motor from the load so that the shaft can rotate freely				
	Specify the maximum permissible process speed and set ID113 accordingly. (ID113 = max. process speed/1,25)				

The 'Startup' function of the AIPEX PRO software gives support to the initial startup and controller tuning. The startup function contains a setpoint generator which can set several curve forms (trapezoidal, square wave, triangular, sinusoidal) for different operation modes (torque, speed, position control).



Before you first put the motor into operation, check the sense of rotation The sense of rotation can be inverted by ID32773, bit16 = 1

The following example shows how to set a positive speed setpoint with acceleration and deceleration ramp. By means of the 'Scope' function of AIPEX PRO, you can display and store the actual motor values.

Starting the 'Startup' function

In the device tree click to that device you want to set a setpoint by the startup function. Click to the 'Startup' menu and subsequent to 'Startup...'.

🚟 Unbenannt - AIPEX PRO		<u>- 0 ×</u>
Project Online Edit View Extras	Startup Configuration ?	
Project Online Edit View Extras	Startup Configuration ? Oscilloscope Open Oscilloscope Save as Socilloscope Save as Initial program loading System booting KW Compact in. Event trace KW 108 1128 2 KW 2 Message Monitor Directmode 0000046304 Initial program loading Temporary parameters Monitor RefFahrt Initial program loading	
KEN 5	Connection 2 X85-X86 Bus name EtherCAT Bus physics ETHERCAT	

The startup function will be released by the AMK service password (500591).



Open the configuration window 'Signal forms'



'Controller enable' RF must be withdrawn.

startup	×
SBM Test signation (SBM) Te	
BE speed co	ontrol 🛃
Test generat	or ready!
INIT	START
STOP	RESET

Example trapezoidal signal:

By means of the trapezoidal signal, you can set a positive and negative speed setpoint with acceleration and deceleration ramp. The example configures just a positive movement.



Now, activate the motor controller (<u>siehe 'Switch-on and -off flow chart' auf Seite 40</u>) The LEDs show the states of SBM, UE and RF (green = active)

The configured movement sequence is started by 'START'.



The movement can be interrupted by 'STOP' and continued by 'START'. 'STOP' and subsequent 'RESET' terminates the sequence.

Display actual values

By means of 'Monitor...', you can display the controller state and actual values.

Check whether a positive setpoint causes a positive speed and an increasing position value. A positive rotation direction means clockwise rotation with view to the motor shaft



By means of the AIPEX PRO oscilloscope, you can store and interpret the movement.



Configuring the oscilloscope: Siehe 'AIPEX PRO settings' auf Seite 51.

6.4 Setting the control loop



To set the control loop, the motor must be coupled to a load.

	Motor shaft movement!
	Unintended motor shaft movement is caused by errors in the motor control. Depending on the type of machine, this may have lethal consequences. Possible causes include the following:
	Operator errors
	Controller or application program faults
	Faulty setpoint specification and scaling
	Improper operating mode
	Steps to prevent:
	Never allow personnel to remain in the vicinity of the machine while it is operating.
	 Always ensure that the machine is fully de-energised before commencing work on the machine or within the machine's vicinity.
	Specify the maximum permissible process speed and set ID113 accordingly.

The control loop has a cascaded structure.

Only the control loops of those operation modes must be optimised which will be active in the process.



The parameters which were reduced during the initial startup, must be adapted to the application before the control loop is optimised.

- ID38 'Positive velocity limit'
- ID39 'Negative velocity limit'
- ID82 'Positive torque limit'
- ID83 'Negative torque limit'

6.4.1 Tuning the current controller

On asynchronous servo motors (AMK and third-party), an automatic current controller adjustment will be executed for the first RF 'Controller enable' on initial loaded inverters. The detected data are saved in the serial EEPROM (SEEP) of the inverter.



The automatic current controller adjustment will be repeated at any modification of ID111 'Motor nominal current IN' as soon as RF is set first after mains OFF / ON.

On AMK synchronous servo motors, the current controller parameters are transferred to the inverter from AIPEX PRO data base or from the encoder data base.

Siehe 'Motors with encoder data base' auf Seite 30. Siehe 'Motors without encoder data base' auf Seite 32. On synchronous third-party motors, the values of ID34050 'Current path Q integral-action time TN', ID34052 'Current path D integral-action time TN', ID34151 'Current path Q proportional gain KP', ID34152 'Current path D proportional gain KP' must be determined metrologically or mathematically and entered manually.

Entering the determined values: Siehe 'Third-party motors' auf Seite 33.

In general:



ID34050, ID34052, ID34151 and ID34152 = 0: (values of SEEP are valid) ID34050, ID34052, ID34151 and ID34152 ≠ 0 (parameter values are valid)

6.4.2 Tuning the speed controller

By means of the AIPEX PRO startup function, a square wave speed setpoint step-change is preset. The step response is recorded with the AIPEX PRO oscilloscope.

The controller parameters ID100 'Speed control proportional gain KP', ID101 'Integral-action time speed control TN' und ID102 'Differentiating time speed control TD' are displayed and tuned in the temporary parameter list and therefore are directly valid in the drive.

This chapter describes how to tune the speed controller by means of AIPEX PRO.

The Function descriptions (Part no. 203878), chapter 'Setting the control loop', describes the general procedure of tuning the speed controller.



6.4.2.1 Theoretical basis

The PID speed controller needs to be set and optimised depending on the application.

The precise mathematical description of all parameters of the control circuit has been shown often to be rather extensive and difficult in practical applications. Therefore, a simple procedure shall be presented here by which the controller can be set practically.

For that, a speed step-change (without ramp) needs to be given as a reference variable at the input of the controller. The step response (speed actual value) should be recorded for evaluating the controller setting. When specifying the speed step, make sure that the drive remains operating below the torque limit.

Set the controller as follows:

- 1. Setting ID100 'Speed control proportional gain KP' K_p , with ID101 = 0 (T_n), ID102 = 0 (T_d)
- 2. Setting ID101 'Integral-action time speed control TN' T_n , with ID100 = const. (K_p), ID102 = 0 (T_d)
- 3. Setting ID102 'Differentiating time speed control TD' T_d , with ID100 = const. (K_p), ID101 = const. (T_n)

Step response of the optimised speed control circuit



For an optimally set PID controller, the actual speed value may overshoot a setpoint step-change by no more than 20%.



Two PT1 filters can be configured at the output of the speed controller. See ID32928 'Time filter 1' and ID32929 'Time filter 2'

Relevant parameters:

Parameter	Name
ID100	'Speed control proportional gain KP'
ID101	'Integral-action time speed control TN'
ID102	'Differentiating time speed control TD'
ID32928	'Time filter 1'
ID32929	'Time filter 2'

Setting the proportional gain $\mathbf{K}_{\mathbf{p}}$

Set ID102 ('Differentiating time speed control TD', T_d) and ID101 ('Integral-action time speed control TN', T_n) to 0, the controller then works as proportional controller.

By increasing ID100 'Speed control proportional gain KP' K_P , the controller should be made to overshoot (50 % overshoots). The actual speed has a course then similar to the curve with the solid line:



Halve the determined value for 'Speed control proportional gain KP' KP and enter the halved value in ID100.

Setting the reset time T_n

Using the integral proportion (I-proportion) in the controller, the controller deviation resulting from the P controller is adjusted. The integration time is reduced (starting at an initial value e.g. 100ms) until the settling time is minimal. If the reset time is set optimally, the actual speed value curve (jump answer) roughly follows the curve with the solid line:



For an optimally set PI controller, the actual speed value may overshoot a setpoint jump by no more than 20% as an answer.

t

Setting the differential time T_d

The differentiating time T_d is extended until the desired dampening of the jump answer is reached. The curve with the solid line serves as a reference point for setting the D-share.



6.4.2.2 AIPEX PRO settings

Configuring the oscilloscope



Open the 'Channels configuration' window (3).

Channels configuration (online)	×	
1 - Antrieb 1		
Signal	Channels configuration (online)	×
10 00040 Velocity feedback value	1 - Antrieb 1	
<u></u>	Signal	
Trigger-	11D 00084 Torque feedb.val	
Type Positive edge	6	
Level 5 1/min	Trigger	
	Type not active	
Time 10 x samp	Level 0 Nm	
Channel active	Time 10 x Sampling time (5 ms)	
СН 1 СН 2 СН 3 СН 4 СН 5 С		
<u> </u>	Channel active	
OK all reset	СН1 СН2 СН3 СН4 СН5 СН6 СН7 СН8	
	<u>15</u>	
	OK all reset Cancel	

CH1:

- Signal: ID40 'Velocity feedback value'
- Trigger:
 - Type: Positive edge
 - Level: 5 1/min (the recording is started when the actual speed value exceeds 5 rpm)

CH2:

- Signal: ID84 'Torque feedback value'
- Trigger: not active

CH3:

- Signal: ID34299 'Velocity setpoint in control'
- Trigger: not active



Activate the configured signals by the pull-down menu 'CH - ID Parameter name'



Maximum recording time

The maximum recording time is affected by the variable data memory size, as well as the configured measuring signals and the sampling time

The data memory in the drive can be configured with ID34284 'OSC container length'. The default value is 4096 bytes, the maximum value is 32600 bytes.

See: AIPEX PRO documentation

Topic: Scope - Maximum recording time

Configure 'Temporary parameters...'

Open the 'Temporary parameters...' window in the 'Startup' menu.



Temporary parameters	×		
8 Parameter Selection:			
1			
	Parameter Selection		×
<	C All parameters C Single group Own list	Torque parameters Tuning, 38, 39, 82, 83, 100, 101, 102, 1	OK Canca
P-Set 0	System internal parameters		
	Admit changes (password)		

Configure your 'Own list' by entering a name and the parameter IDs which are relevant for the controller settings. We recommend the following input:

>own list name<,38,39,82,83,100,101,102

Display own list 'Tuning':

Temporary parameters 🛛 🗵							
📰 Parameter Selection: Tuning							
🙀 ID	🏘 Name	M Value 🔺					
39	Neg. velocity limit	-500					
82	Positive torque limit	120					
83	Negative torque limit	-120					
100	Prop.gain speed control	60					
101	Integr.act.time sp.ctrl	10.0					
102	Diff.time speed control	0.0					
104	Position loop KV-factor	400					
<u> </u>							
P-Set (ป						

Configure 'Startup function' (Test generator)

Preparation (test generator without CAN control)

The inverter needs the signal RF controller enable to energize the motor. RF can be set for testing via a hardware switch. For this, the following parameters must be adapted.

Additionally deactivate the special functionality FSE, so that you can use the 'Test generator'.

Hardware

Wire the required RF controller enable signal via a hardware switch to terminal X140 on the controller card.

X140 connection 3B: 24 VDC

X140 connection 1B: 0 VDC Reference potential

Parameterization

'Binary inputs assignment' is used to set the code RF controller enable to assigned to the binary input ID32978 'Port 3 Bit 0' Input value: 32904 (meaning: Code RF inverter enable)

The 'System parameters' group is used to set the controller enable RF source hardware. ID32796 'Source RF' Input value: 0 dec (meaning: RF via digital input)

The 'System parameters' group is used to deactivate the FSE special function. ID32901 'Global service bits' Input value: 0x240 (meaning: FSE special function deactive)

Open 'Startup...' (Test generator...') in the 'Startup' menu (PW: 500591).

🚟 Unbenannt - AIPEX PRO									
Project Online Edit View Extras	Startup Configuration ?								
	Oscilloscope Open Oscilloscope Save as								
EtherCAT · Connector	Initial program loading System booting Event trace			-1	+	1	ł		View3
	Message Monitor Directmode V Temporary parameters Monitor	1.0 1.5	2.0	2.5	3.0	3.5	4.0	4.5 5.	
	Startup	CH - ID Param	eter name		Y-Value1	Y-Value2	Y Scale	Y-Offset	Unil 🔺 CH
	1 - Antrieb 1	CH1 - 00040	Velocity feedba	ick value 💌	1		20	0	1/m +
	1 - Antrieb 1	CH2 - 00084	Torque feedb.v	val 💌	ļ				Nm 🚽 🗀
ONLINE	Die	Stop Trigger	Sampling	time Ti 5 ms	rig.position	Trigger c And	J ombination O Or	🛠 Conf	iguration
Startup control bar									

Select 'Rectangle setpoint' as speed setpoint step-change.



The following measured actual torque value has always to be less than the set torque limits. If the torque limits are exceeded, the value of 'Amplitude High (Ah)' must be reduced. Recommended start value: 100 1/min

startup	×				
 SBM Test signal : UE RF Test generator ready! 	Signal forms				X
INIT STA					
	Rectangle s	etpoint 💌			
STUP	Amplitude High (Ah)	100	rpm	A _h	<u> </u>
	Amplitude Low (Al)	0	rpm		
	Accel, Ramp (Tr)	0	ms		
	Time High (Th)	500	ms		t
	Decel. Ramp (Tr)	0	ms	A	
	Time Low (TI)	0	ms		T _h T _l
	Number of periods	1 () - endless		
	Frequency	1	Hz		
		ок 👆	3	cel	

6.4.2.3 Optimising the speed controller

Repeat the steps to optimize the speed controller until the controller behaviour meets your idea of dynamic and rigidity. In the 'Temporary parameters' window, you can enter the parameter values before you take a new measurement. The input is directly valid.

🐨 Unbenannt - AIPEX PRO										star	tup		×	
Project Online Edit View Extras Startup	Co	nfigural	ion ?	.						٠	SBM	Test signal : 🕂 🕂		
		Cursor	2								UE	speed control	•	
EtherCAT - Connector		81	-						s		nr	Configuration valid		
⊕-grj Antrieb 1		4 2 -2 -4 -6						ms	W3 4		INI	BESET	2	
	-	-8] 10]							ew4		010			
	Ŀ							- 44 bb :		Ten	npor	ary parameters		×
	Ē	Math	Drive	CH - ID Para	meter	r nama	V-Value1	V-Value2	існ І	::::	Para	meter Selection: Tuning		
	╟─	naun	1 - Antrieh 1	CH1 - 00040	Velo	n name noity feedback value	-0.1860		+	<u>å</u> å	ID	🙀 Name	M Value	Unit
	╠╴	0	1 - Antrieb 1	CH2 - 00084	Torc	oue feedb.val	- 0.0				38	Pos. velocity limit	100	1/min
	l'a										39	Neg. velocity limit	-100	1/min
							.				82	Positive torque limit	10	% MN
ONLINE			Charl	0 T.:		Sampling time	l rig.position	I rigger			83	Vegative torque limit	-10	% MN
		started	Start	stop ingger		5 ms	20 %	🕥 And 🕕			100	Prop.gain speed control	60	
			1			,	,				101	integr.act.time sp.ctrl	10.0	ms
							<u></u>				102	Diff.time speed control	0.0	ms
											104	Position loop KV-factor	400	
										P	Set O	J		

After the measurement has finished, the results are transferred to the PC and displayed automatically.

Interpret the measurement.

By means of 'Temporary parameters', you can optimise the P part (ID100), I part (ID101), and D part (ID102). The button 'HOLD' saves the selected value so that you can compare it to the next measurement.

뺆 Unbenannt - AIPEX PRO		
Project Online Edit View Extras Startup	Configuration ?	
🗋 🗅 🚔 🔲 😔 😫 🌾 👘 🗣 🖓	X 🗞 😫 🍊 🖕 🕾 -	
⊡…)) PC ⊡ 幸 EtherCAT - Connector 	1Cursor2 8 6 4 2 2) -2 50 100 150 200 250 3 -4 -6 -8	300 350 400 450 500 550 600 650 time difference : «0.0»
	-10 ¹ CH - ID Parameter name	Y-Value1 V Scale V-Offset Unit Hold CH
	CH1 - 00040 Velocity feedback value 💌 0	0.007 20 ÷ 0 ÷ 1/min HOLD +
	CH2 - 00084 Torque feedb.val	
DNLINE Co Pa A Me A Scc + Dia	ready Start Stop Trigger	Sampling time Trig.position Trigger

6.4.3 Tuning the position controller

The dynamic of the position control loop depends on ID104 'Position loop factor KV'



6.4.3.1 Theoretical basis

Setting the proportional gain K_{ν}

The proportional gain of the position controller (P controller) is set in ID104 'Position loop factor KV'.

The following image shows the step response of the actual position value on a step-change position setpoint. In optimised state, the drive positions comparable to the solid line without overshoots:

Step response position controller, effect of ID104 'Position loop factor KV'



The following conditions have to be kept:

Formula: System internal limitation of K_v

LA = factor position resolution (depends on encoder type)

Motor encoder as position value encoder

LA = ID116 'Resolution motor encoder'

External encoder rotatory:

Formula: factor position resolution on external position value encoder

ID117 'Resolution external position feedback system' (Strichzahl pro Umdrehung) ID122 'Load gear output revolution' ID121 'Load gear input revolution'

6.4.3.2 AIPEX PRO settings

D116 'Resolution motor encoder'

Set ID116 'Resolution motor encoder' as high as possible.



Calculation of ID116: See Parameter description, Part no. 203704. The maximum value depends on the motor encoder system. The calculated value of ID116 might not be used because it is limited by the higher-ranking controller. Enter a smaller value.

Configure the oscilloscope

Extend the oscilloscope configuration to record ID51 'Position feedback value' and ID32896 'Internal position command value' Procedure: Siehe 'AIPEX PRO settings' auf Seite 51.

Configure 'Temporary parameters' window

Extend the temporary parameter list with ID104 'Position loop factor KV' and ID159 'Excess error'. Procedure: Siehe 'AIPEX PRO settings' auf Seite 51.

Configure startup function



The following measured actual torque value has always to be less than the set torque limits. If the torque limits are exceeded, the value of 'Amplitude High (Ah)' must be reduced. Recommended start value: $\frac{1}{2}$ motor rotation ($\frac{1}{2}$ ID116)

Diagnostic message 2318 'Control deviation' ID159 'Excess error' monitores the following error. Adjust the monitoring to your calculated value ID116

Configuration example (ID32776 = 512, PV = 2048) ID116 'Resolution motor encoder' = 4 x ID32776 'Sine encoder period' x PV ID116 = 4 x 512 x 2048 = 4194304 increments

¹/₂ motor rotation = 4194304 incr./ 2 = 2097152 incr.



Following error monitoring

The proportional gain K_v directly influences the size of the following error. The higher K_v , the smaller the resulting following error. The following error is calculated as follows:

If the difference between actual position value and position setpoint (= following error) exceeds ID159 'Excess error', RF (controller enable) is withdrawn, SBM reset and diagnostic message 2318 'Control deviation' is generated. Adjust ID159 to the maximum permitted following error of your process.

6.4.3.3 Optimising the position controller

Execute the steps of 'Optimising the position controller' until the controller behaviour meets your idea of dynamic and rigidity.

7 Initial startup fieldbus



7.1 Overview fieldbus wiring

For fieldbus connection, use an Ethernet standard RJ45 twisted pair patch cable.



7.2 Direct connection via Ethernet



A direct connection is a point to point connection between PC and AMK controller.



See document Device descriptionControllers A4 / A5 / A6 (Part no. 202975), chapter 'Connection via Ethernet Interface X20'.

7.3 System run-up fieldbus



In case of a device error during the initialisation:

Status LED SBM = red (LED H0 (controller), H1 (compact power supply) or H2 (KW-R06 / -R16 / -R07 / -R17 / -R24(-R) / -R25 / -R26))

Siehe 'Error diagnosis with AIPEX PRO' auf Seite 67.



Only with an existing and valid xml configuration file, the fieldbus participants switch from pre-operational state to operational.

7.4 Logon fieldbus

🚟 Unbenannt - AIPEX PRO		- 🗆 🗵
Project Online Edit View Extras Startup	Configuration ?	
🗋 🗅 🚅 🖬 4 🖳 🚆 🕷 🗰 🚔 4	📕 🐰 ங 📾 😂 🏊 🏝	
	Properties - PC Serial connector Picture Ethernet CAN-adapter EtherCAT EtherCAT USB-adapter SERCOS III CAN-Gateway CAN-Gateway	
Offline ① Config 🗔 Paran 🔗 Mess, 👭 Scopi	Components Device Name Display all elements AMMANAC Controller Addes Accept Select one device from the available components and take it in the device tree by double-click.	

Click 'Logon' to open the 'Import online' window



Click 'Accepted to the project complete' to import the detected devices.

W Unbenannt - AIPEX PRO		
Project Online Edit View Extras Startup		يت اكار
	1 X 1 2 12 12 12 12 12 12 12 12 12 12 12 12 12 1	
	Properties - PC Serial connector	
	Components Device Name	
	Display all elements	
1) Cor 🔄 Pai 🄗 Mei 👫 Sci 🕂 Dia	Accept device from the available components and take it in the device from the available components and take it in the device tree by double-click.	× •

End of initial startup

8 PLC programming

The startup of AMKAMAC A series PLC controllers is described in the device description 'Controllers A4 / A5 / A6' (Part no. 202975)

You will get guidance and hints for PLC programming in the following documents:

- Basic knowledge AMK PLC programming in structured text (Part no. 204019) This documentation describes the introduction in programming according to IEC 61131-3 with the programming software CoDeSys and the AMK function libraries. It explains the various modules, variables, data types and the instruction codes of the programming language Structured Text.
- Software description AFL AMK function libraries, (Part no.205795) includes AFL AMK Function Library, part 1 standard function blocks and AFL AMK Function Library, part 2 application blocks
 The AMK Function Library contains standard function blocks which offer simple access to any standard functions of the controllers, power supplies and drives. The application blocks of the AMK Function Library offer further PLC functions for the drive control, e. g. print mark control or NC motion.

You can get the AMK Function Library with the AMK order no. O877.

9 Error diagnosis with AIPEX PRO

With 'Diagnostics', the diagnostic messages can be read out from the selected device.

Click on each message to receive an explanation for it. You get further information if you analyse Info (I), I2 and I3 The first message of the list is the main activator of the fault; further displayed numbers might be resulting errors which will not appear any longer after rectifying the cause of the first diagnostic message.

Button 'New reading'

Diagnostic messages will be read out from the selected device.

Button 'Error reset'

The errors will be deleted in the selected device .

Button 'Error reset - via BUS'

The errors of all devices of a bus line will be deleted. To do this, select the bus in the device tree.

After the causing error is rectified successfully, 'Error reset' activates a system restart and the system ready message SBM is set.

Diagnosis with AIPEX PRO (tab 'Diagnostics')

🐝 Unbenannt - AIPEX PRO	
Project Online Edit View Extras Startup	Configuration ?
📙 🗠 🖨 😫 🕱 🍋 🖿 🚽	📕 X ங 📾 😂 🎦 🛎 🍮
E…D PC	Number Text Class (K) Modul (Code (F) / Info (I) 2 13 14 (Adr)
EtherCAT - Connector	1 2311 2311 Encodersignal 4 5 7 1 0 0 0
	\sim
Motor	
E - I KW-R06	
	New reading Error reset From reset - via BUS
	2311 Encoder signal
	Motor encoder defective
	Encoder cable defective or not connected
	Motor is equipped with a D encoder
	Possibly A encoder with defective field plates
	The SINE encoder monitoring can be switched off through ID32773
	Device
	Description
	Class
	Drive Drive runs down
	Device Single treatment
	Behaviour
	Additional Error Information (AMK Service)
	Info 1 1 A/I/T encoder hardware:
	Inadmissible level at the encoder input
	2 I/T encoder amplitude:
	The amplitude at the A/D converter input of an
🔍 Loj 🔄 Paj 🚰 Maj 👫 Soj 🔶 Diaj	encoder track is less than 0.6 V

Diagnosis in direct mode



Glossary

Α

A4 / A5 / A6 AMKAMAC controller A4 / A5 / A6

ACC

AMK CAN Communication (CAN bus interface with standard CANopen protocol DS301 and additional hardware synchronization signal)

AIPEX

AMK startup and parameterizing software (PC software): Programming, parameterization, configuration, diagnosis, oscilloscope, status information

С

CAN

Controller Area Network

D

DC bus on Converter on

Default Factory setting

DZR Speed control

E EF

Power output stage enable

EF2 Power output stage enable

E-encoder Absolute encoder, singleturn, EnDAT 2.1 with additional sine and cosine track

EtherCAT Real-time Ethernet bus

7

FL Command (Causes a new system run-up)

F-encoder Absolute encoder, multiturn, EnDAT 2.1 with additional sine and cosine track Firmware

System software, loaded by AMK

ł

H-encoder

Encoder with Hall sensors (Contains one sine and cosine track per rotation or per pair of poles on linear measuring systems)

iC

AMKASMART decentralized inverter with power supply

ID

Parameter identification numbers acc. to SERCOS Standard

iDT

AMKASMART Servo motors with integrated inverter

I-encoder

Incremental encoder, optical encoder with sine and cosine track and zero pulse

iX AMKASMART decentralized inverter

Κ

KW AMKASYN compact inverter

KWD

AMKASYN compact double inverter to control two motors

KP

Proportional gain (speed control, PID controller)

KW-Rxx

AMKASYN controller card for installation into compact inverter

KEN AMKASYN compact power supply without recovery

KES

AMKASYN compact power supply with sinusoidal voltage and current

Kv

Position loop factor

KE

AMKASYN compact power supply with recovery

KE/KW

Modular AMK drive system (contains compact power supply KE, compact inverter KW with controller card and applicable option card)

L

LR

Position control

Μ

MDB

Motor database; it contains information about all AMK motor parameters

0

Operational

In state operational, data are transferred cyclically via fieldbus

Ρ

Parameter Identification number acc. to SERCOS standard

PDK_xxxxxx_abcdefgh

Product documentation; xxxxxx - AMK part no., abcdefgh - name

P-encoder Absolute encoder singleturn, EnDAT 2.2 light

Pre-operational

In pre-operational state, the controller can access the bus participants via the service channel. No cyclic data is exchanged.

Q

Q-encoder

Absolute encoder multiturn, EnDAT 2.2 light

QRF

Acknowledgment controller enable; the drive is controlled in the activated operation mode

QUE

Acknowledgment DC bus on; shows that DC bus is loaded

R

RF

Command 'Controller enable'; the drive is energized and will be controlled depending on the selected operation mode. Controller enable can only be set if the device is error-free (SBM = TRUE) and acknowledgement DC bus on is set (QUE = TRUE).Acknowledgement controller enable (QRF) is set.

Resolver

Absolute angle encoder singleturn (1 sine and cosine track per rotation)

R-encoder

Absolute angle encoder singleturn (1 sine and cosine track per rotation)

S

SafePMT

Safe parameter editor

SBM

System ready message; shows that the device is error-free In case of error. SBM will be reset

SEEP

Device-internal memory, serial EEPROM

S-encoder

Absolute encoder, singleturn, RS485 Hiperface with sine and cosine track

Sense of rotation

Clockwise rotation of motor with view to the motor shaft and positive setpoint

SERCOS

Standardized digital interface for communication between controller and field bus participants.

T

Td

Differentiating time in speed control (PID controller)

T-encoder

Absolute encoder, multiturn, RS485 Hiperface with sine and cosine track

Tn

Integral-action time in speed control (PID controller)

U

U-encoder

Absolute encoder, singleturn, RS485 Hiperface with sine and cosine track

UE

Command 'DC bus on' control signal to load the DC bus e.g. in KE. DC bus on can only be set if the device is error-free (SBM = TRUE). After the DC bus is loaded, the acknowledgement message QUE is set.

UZ

DC bus (voltage)

V

V-encoder

Absolute encoder, multiturn, RS485 Hiperface with sine and cosine track

Your opinion is important!

With our documentation we want to offer you the highest quality support in handling the AMK motion products.

That is why we are now working on optimizing our documentation.

Your comments or suggestions are always of interest to us.

We would be grateful if you take a bit of time and answer our questions. Please return a copy of this page to us.



e-mail: Documentation@amk-motion.com or fax no.: +49 7021/50 05-199

Thank you for your assistance. Your AMKmotion documentation team

1. How would you rate the layout of our AMKmotion documentation?

(1) very good (2) good (3) satisfactory (4) less than satisfactory (5) poor

- 2. Is the content structured well?
 - (1) very good (2) good (3) moderate (4) hardly (5) not at all
- 3. How easy is it to understand the documentation?

(1) very easy (2) easy (3) moderately easy (4) difficult (5) extremely difficult

4. Did you miss any topics in the documentation?

(1) no (2) if yes, which ones:

5. How would you rate the overall service at AMKmotion?

(1) very good (2) good (3) satisfactory (4) less than satisfactory (5) poor

AMKmotion GmbH + Co KG Phone : +49 7021/50 05-0, fax: +49 7021/50 05-199 E-Mail: info@amk-motion.com Homepage: www.amk-motion.com